

# NEONS Application Instructions



Applies to 100% Cotton, Poly/Cotton Blend

## 1. Set Heat Press

**Temperature:** 375°F

**Press Time:** 8 Seconds

**Pressure:** Heavy / 40 psi

**Release Time:** 3 Seconds then peel

## 2. Pre-Heat Apparel for 3 Seconds

## 3. Position Transfer and Press

- Close heat press and press for 8 seconds.

## 4. Remove Transfer Paper

- Open heat press gently and wait 3 seconds to peel away the transfer paper.

### Garment Care Instructions

Apparel should be laundered without bleaching agents, using a mild detergent and warm water. Hang dry.

### Tips:

Pre-Test On All Fabrics For Compatibility.

Don't use a craft sheet or pillow.

Instructional videos at [www.thewildside.com](http://www.thewildside.com)



[www.thewildside.com/blog](http://www.thewildside.com/blog)

[www.facebook.com/ShopWildSide/](https://www.facebook.com/ShopWildSide/)  
[shopthewildside](https://www.instagram.com/shopthewildside)

### Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of the extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

## First Time?

Call us. . .

Our experienced staff will walk you through everything!

(800) 421-3130  
(818) 837-5000

Monday - Friday  
7:00am-4:30pm

# WildSide