

HD DARKSIDE Application Instructions



Applies to 100% Cotton, Poly/Cotton Blend

1. Set Heat Press

Temperature: 385°F

Press Time: 10 Seconds

Pressure: Heavy / 40 psi

Release Time: Peel hot/right away

2. Pre-Heat Apparel for 3 Seconds

3. Position Transfer and Press

- Close heat press and press for 10 seconds.

4. Remove Transfer Paper

- Open heat press gently and immediately peel away the transfer paper.

Garment Care Instructions

Apparel should be laundered without bleaching agents, using a mild detergent and warm water. Hang dry.

Tips:

Pre-Test On All Fabrics For Compatibility.

Don't use a craft sheet or pillow.

Instructional videos at **www.thewildside.com**



www.thewildside.com/blog

www.facebook.com/ShopWildSide/
[shopthewildside](https://www.instagram.com/shopthewildside)

Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of the extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

First Time?

Call us. . .

Our experienced staff will walk you through everything!

(800) 421-3130
(818) 837-5000

Monday - Friday
7:00am-4:30pm

WildSide